

# Product Operation Manual

**3+**  
**AGES**

Thank you for choosing our product! Please read this instruction manual carefully before using, as it contains all the informations you need to know about how to use this product correctly with fun.


Colors And Contents May Vary From Illustration.

**27MHZ**




## Battery Installation

ON/OFF



• Vehicle requires 4-AA batteries. (Not included)


Replacing batteries of the transmitter



• Controller requires 2-AA batteries. (Not included)


Power Requirement (Not Included) ☐

## Remote Control Operation




MADE IN CHINA


## The Basic Operation of The Products




Forward



Backward



360°Rotation



BACK AND FORTH SWING BODY

### CAUTIONS

When the car is in motion, do not touch the wheels by hand to avoid damages to the car.



When there's more than one car played in the same place, set the cars to different frequency to avoid mutual interference.

Do not bend the antenna or point it at other people or articles to avoid hurts.



Do not play in a place with puddle, mud or sand.

Do not play on the roads or in any other dangerous places to avoid accidents.

### BATTERY SAFETY

- (1) The placement or replacement of batteries is to be performed by an adult.
- (2) Remove the rechargeable battery from the chassis before charging.
- (3) Always remove exhausted batteries from the car and the transmitter.
- (4) Make sure the main switch is set to OFF before installing the battery pack into the car body.
- (5) Batteries must be inserted with the correct polarity.
- (6) Non-chargeable batteries shall not be recharged.
- (7) Do not short-circuit the batteries.
- (8) Always remove the batteries from the car and the transmitter after playing.
- (9) Never throw the batteries into fire to avoid explosion or leakage.
- (10) Do not mix batteries from different producers or new and old batteries.
- (11) You should only use batteries of the same or equivalent types as recommended.
- (12) Check the batteries on a regular basis to avoid leakage.
- (13) Keep this manual well for future reference as it contains important information about this product.

| Situation         | Cause                                                                                                                                                                                                                                                                                                                                           | Solution                                                                                                                                                                                                                                  |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Car does not move | The car or controller battery was not properly inserted<br>The car or controller power was switched OFF<br>The car AA battery or Rechargeable battery is drained of power<br>The controller battery is drained of power<br>Radio intermittent during signal transmitting<br>The safety feature have switched on due to the high car temperature | Re-insert the battery correctly as indicated<br>Switch the car or controller power ON<br>Change AA battery or re-charge the Rechargeable battery<br>Change the battery<br>Re-Start the On/Off Power<br>Rest for 5 minutes to cool the car |

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



**WARNING:**

**CHOKING HAZARD** - small parts,  
Not for children under 3 years.



**GOODLY**

Item No. 5588-612

Goodly Toys Limited  
Room 502A, Harbour Crystal Centre,  
100 Granville Road, TST East, Kowloon, Hong Kong  
sales@goodlytoys.com